

1. Ensure the scanner is powered-down, then place it on its side as shown below.
2. Install the four Leveling Feet by threading them into the pem nuts in the bottom of the mount as shown in the illustration.
3. Place the scanner face-up and position it on the installed shelf surface where it will be installed.
4. Leveling feet can be individually adjusted (tighten screw to lower, loosen to raise) to correct the scanner's height at each of its corners. A correctly installed scanning surface is slightly lower on the leading edge than the countertop and slightly higher on its trailing edge in order to allow products to be smoothly swept across the scan zone without meeting obstacles.

